



**Wolfgang Moersch Photochemie
Am Heideberg 48
50354 Hürth**

Tel: ++49 (0) 2233 943 137

Fax: ++49 (0) 2233 943 138

Email: wolfgang@moersch-photochemie.de

Cyanotype

Coat with brush or rod.

Exposure with daylight or UV-light.

Develop 5-10 minutes in Nitric acid 1% (dilution 1+20) or Citric acid 1-2%

Wash 5-15 minutes

Oxidation bath Hydrogen peroxide 0,3% (dilution 1+100) 30 seconds

Final wash 2-5 minutes